Fuse Block

Solenoid

Battery

Fuse
Block

To Power LED

Switch

Key on power